



# PRESSURE INDICATOR

## PRESSURE INDICATOR WITH ROD

Pressure indicators are used to check pressure in the main or secondary line.

Pressure indicator with **rod** and **spring**: the pressure acting on a small hardened, ground and polished piston that moves the rod.

They are available for pressure up to 250bar (3600psi).



### PRESSURE INDICATOR WITH ROD


#### N-TYPE

In the spring loaded the pressure acts on a small hardened and ground piston which displaced the indicator rod when the set pressure is reached. The indicator returns when pressure returns to zero.

**Height: mm 31,5 (1,22 in.)**

**Key: mm 12 (0,47 in.)**

**Thread: 1/8 BSP**



### PRESSURE INDICATORE WITH MEMORY ROD


#### M-TYPE

This device is very useful for checking the secondary supply line. The indicator rod X moves out when an abnormal pressure rise occurs in the line where the indicator is fitted due to blockage of the lubricant to the bearing. A locking device prevents the return of the rod and indicates the fault to the operator. The indicator rod is released by lifting lever.

**Height: mm 43 (1,69 in.)**

**Key: mm 12 (0,47 in.)**

**Thread: 1/8 BSP**



## ORDERING INFORMATION

CODE	DESCRIPTION
Tipo N	
<b>3290019</b>	Pressure indicator 1/8 BSP – 20 Bar/300Psi
<b>3290006</b>	Pressure indicator 1/8 BSP – 30 Bar/450Psi
<b>3290007</b>	Pressure indicator 1/8 BSP – 50 Bar/750Psi
<b>3290008</b>	Pressure indicator 1/8 BSP – 100 Bar/1500Psi
<b>3290009</b>	Pressure indicator 1/8 BSP – 150 Bar/2200Psi
<b>3290010</b>	Pressure indicator 1/8 BSP – 200 Bar/2900Psi
<b>290011</b>	Pressure indicator 1/8 BSP – 250 Bar/3600Psi

CODE	DESCRIPTION
Tipo M	
<b>3290000</b>	Pressure indicator 1/8 BSP – 30 Bar/450Psi
<b>3290001</b>	Pressure indicator 1/8 BSP – 50 Bar/750Psi
<b>3290022</b>	Pressure indicator 1/8 BSP – 75 Bar/1100Psi
<b>3290002</b>	Pressure indicator 1/8 BSP – 100 Bar/1500Psi
<b>3290003</b>	Pressure indicator 1/8 BSP – 150 Bar/2200Psi
<b>3290004</b>	Pressure indicator 1/8 BSP – 200 Bar/2900Psi
<b>3290005</b>	Pressure indicator 1/8 BSP – 250 Bar/3600Psi
<b>3290021</b>	Pressure indicator 1/8 BSP – 300 Bar/ 4351
<b>3290023</b>	Pressure indicator 1/8 BSP – 350 Bar/ 5076

C2180PE WK 30/17

Dropsa products can be purchased from Dropsa subsidiary and Dropsa sales representatives, visit [www.dropsa.com/contact](http://www.dropsa.com/contact) or contact us [sales@dropsa.com](mailto:sales@dropsa.com)

Info distributor: